






	TYPE		TANDING	CODE 6m		CODE 1,8m	
<b>OFFSETSTRIPS OM TE PERFOREREN</b>	Center	<i>papier</i>	3 tanden	001	A 001	001a	A 001a
		<i>karton</i>	3 tanden	008	A 008	008a	A 008a
	Center	<i>papier</i>	6 tanden	002	A 002	002a	A 002a
		<i>karton</i>	6 tanden	009	A 009	009a	A 009a
	Center	<i>papier</i>	8 tanden	003	A 003	003a	A 003a
		<i>karton</i>	8 tanden	010	A 010	010a	A 010a
	Center	<i>papier</i>	12 tanden	004	A 004	004a	A 004a
		<i>karton</i>	12 tanden	011	A 011	011a	A 011a
	Center	<i>papier</i>	16 tanden	005	A 005	005a	A 005a
		<i>karton</i>	16 tanden	012	A 012	012a	A 012a
	Center	<i>papier</i>	micro 35 tanden	015	A 015	015a	A 015a
		<i>papier</i>	micro 50 tanden	016	A 016	016a	A 016a
<b>OFFSETSTRIPS OM TE BIEGEN</b>	Center	<i>papier</i>		007	A 007	007a	A 007a
		<i>karton</i>		014	A 014	014a	A 014a
							
<b>OFFSETSTRIPS OM TE SNIJDEN</b>	Center	<i>papier</i>		006	A 006	006a	A 006a
		<i>karton</i>		013	A 013	013a	A 013a
							
<b>OFFSETSTRIPS OM TE PERFOREREN</b>	Side	<i>papier</i>	3 tanden	999	A 999	999a	A 999a
		<i>karton</i>	3 tanden	992	A 992	992a	A 992a
	Side	<i>papier</i>	6 tanden	998	A 998	998a	A 998a
		<i>karton</i>	6 tanden	991	A 991	991a	A 991a
	Side	<i>papier</i>	8 tanden	997	A 997	997a	A 997a
		<i>karton</i>	8 tanden	990	A 990	990a	A 990a
	Side	<i>papier</i>	12 tanden	996	A 996	996a	A 996a
		<i>karton</i>	12 tanden	989	A 989	989a	A 989a
	Side	<i>papier</i>	16 tanden	995	A 995	995a	A 995a
		<i>karton</i>	16 tanden	988	A 988	988a	A 988a
	Side	<i>papier</i>	micro 35 tanden	985	A 985	985a	A 985a
		<i>papier</i>	micro 50 tanden	984	A 984	984a	A 984a
<b>OFFSETSTRIPS OM TE BIEGEN</b>	Side	<i>papier</i>		993	A 993	993a	A 993a
		<i>karton</i>		986	A 986	986a	A 986a
							
<b>OFFSETSTRIPS OM TE SNIJDEN</b>	Side	<i>papier</i>		994	A 994	994a	A 994a
		<i>karton</i>		987	A 987	987a	A 987a
